







Vibro Massage Kit Manual

Model No.NHX0322HLL

Controller panel & LCD instructions



➤ Operation manual

- Plug the AC Adapter into a power supply and input the DC end to the outlet of controller.
- Press **ON/OFF** to startup massage kit. It runs from mode 1st to 10th in automatic style (signal  be on, each mode switch to next mode per 1 minute). Default timer is 15 minutes, default intensity is in grade 5. Press **ON/OFF** again to stop work,
- Press **INTENSITY** to choose massage intensity, the signal  will be indicated more until full, totally 10 grades
- Press **AUTO** to set automatic mode circle, and press again to get manual style (signal  lamp will be off), and you can choose ten massage modes.
- Press **TIMER** to set up running time within 5~60 minutes. Default running time is 15 minutes.
- Press **MODE△/MODE▽** to Select different manual vibration mode (signal  lamp will be off), totally 10 styles.
- Press **POINT** to point the certain massage zone such as back or buttocks or thighs or legs.
- Press **HEAT** , the heating function will be on.
- Press **UP**  and **DOWN**  to control the actuator up and down.

➤ How to deal with the trouble case?

| | | |
|---|---|---|
| Vibrators don't work | <ol style="list-style-type: none"> 1、 Controller handset open or not. 2、 Power supply has no good touch with socket. 3、 Whether the transformer is appropriate | <ol style="list-style-type: none"> 1、 Power on the handset, and operate as per the instructions. 2、 Check the power supply has been correctly connected to the socket 3 、 Input: Related Parameter Output:29V/2A |
| Vibrators suddenly stop or runs in wrong order. | <ol style="list-style-type: none"> 1 、 Automatically stop work because of default timer. 2、 wrong operations. 3 、 Connector not be connected well | <ol style="list-style-type: none"> 1、 Restart the handset. 2、 Power off and disconnect with power supply socket, restart and power on after 20 minutes. 3 、 Check all of the related connector and reconnect |

BLIMO.

Nordbutiker AB
 76141 Norrtälje
 +46 10-555 9123
 info@blimo.se